

User's Manual English Movements Caliber

RONDA normtech

- 706.1
- 706.3
- 706.B

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.



Cal. 706.1

Cal. 706.3

- Pos. I** Position of rest (watch running)
- Pos. II** During the blocking time from approx. 11.30 pm–5.30 am, no day dates can be changed using the pusher, because during this time automatic changes are in progress. Pressing the pusher during these times may damage the movement.

Setting sequence for: moonphase display, day of the week, day and time (e.g. after a battery change)

1. Pull crown out to position II (watch is stopped).
2. Set the moonphase display:
 - Turn the hands forward by turning the crown, until the full moonphase position appears.
3. Set the day of the week and date:
 - Turn the crown until the time of 06.00 am appears (= beyond the blocked time period).
 - Using the quick-change correction, set the date with pusher A, and the day of the week of the last full moon with pusher B (see table). Then using the crown, move the hands forwards until the current date appears.

Cal. 706.1

Cal. 706.3

4. Set the time:
 - Turn the crown until the current time is displayed (remember the 24-hour cycle).
5. Push crown back into position I.

Quick-change correction for date:

Press pusher A, until the current date is displayed (remember the blocking period).

Quick-change correction for the day of the week:

Press pusher B, until the current day of the week is displayed (remember the blocking period).

Quick-change correction for the month: (cal. 706.3)

Press pusher C, until the current month is displayed (remember the blocking period).

Full moon dates


	2015	2016	2017	2018	2019
JAN	05	24	12	02/31	21
FEB	04	22	11		19
MAR	05	23	12	02/31	21
APR	04	22	11	30	19
MAY	04	21	10	29	18
JUN	02	20	09	28	17
JUL	02/31	19	09	27	16
AUG	29	18	07	26	15
SEP	28	16	06	25	14
OCT	27	16	05	24	13
NOV	25	14	04	23	12
DEC	25	14	03	22	12

Applies to all calibers:

Battery type: 371/SR920SW (Ø 9.5 mm x 2.05 mm)

Precision: +20/-10 seconds per month





Cal. 706.B

Pos. I Position of rest (watch running)

Pos. II *During the blocking time mentioned below, automatic changes are in progress. Pressing the pusher during the blocking time may damage the movement.*

- *Pusher A (quick-change correction for the day of the week) must not be pressed during the blocking time from approx. 11.30 pm–5.30 am.*
- *Pusher D (quick-change correction for the calendar week) must not be pressed during the blocking time from Sunday–Monday.*

Setting sequence for: moonphase display, date, day of the week and time (e.g. after battery change)

1. Pull the crown out to position II (watch stopped).
2. Set the moonphase display:
 - Turn the crown clockwise past midnight, until the full moon position appears.

Cal. 706.B

3. Set the day of the week:

- There is no quick-change correction available to change the day of the week, and so the day of the week must be changed as follows. Change the time display by turning the crown backwards and forwards (↶/↷) (↶↷ 01.00 am/↷↶ 10.00 pm/↶↷ 01.00 am/↷↶ 10.00 pm/↶↷ 01.00 am ...), until the day of the week of the last full moon is displayed.

4. Set the date:

- Turn the crown until 06.00 am appears in the time display (= beyond the blocking time).
- Set the date of the last full moon with pusher A. Then with the crown move the hands forwards until the current date is displayed.

5. Set the time:

- Turn the crown, until the current time is displayed (NB remember the 24-hours cycle!).

6. Set the calendar week:

- Using pusher D, set the current calendar week (blocking period Sunday–Monday).

7. Push the crown back into position I.

Cal. 706.B

Quick-change correction for date:

Press pusher A, until the current date is displayed (remember the blocking period between 11.30 pm–5.30 am).

Quick-change correction for the calendar week:

Press pusher D, until the current calendar week is displayed (remember the blocking period between Sunday–Monday).

Full moon dates

	2015	2016	2017	2018	2019
JAN	05	24	12	02/31	21
FEB	04	22	11		19
MAR	05	23	12	02/31	21
APR	04	22	11	30	19
MAY	04	21	10	29	18
JUN	02	20	09	28	17
JUL	02/31	19	09	27	16
AUG	29	18	07	26	15
SEP	28	16	06	25	14
OCT	27	16	05	24	13
NOV	25	14	04	23	12
DEC	25	14	03	22	12

Applies to all calibers:

Battery type: 371/SR920SW (Ø 9.5 mm x 2.05 mm)

Precision: +20/-10 seconds per month

